

# CONMURRA TRAILER HYDROBATH

by FIDO'S®

*Congratulations on the purchase of your new Conmurra Trailer Hydrobath by Fido's. The instructions below are a guide to getting the best out of your hydrobath. Please feel free to contact us or visit our website [www.fidos.com](http://www.fidos.com) if you have any other questions or need further information.*

## INTRODUCTION TO THE HYDROBATH

The hydrobath is constructed of fibreglass. Fibreglass is lightweight, strong, durable and easily cleaned.

Underneath the floor of the hydrobath is a ¾ HP Davey chemical resistant pump, especially made for hydrobaths.

Built into the floor and the side of the hydrobath are two separate tanks. One of these holds fresh water (the holding tank – 100L capacity) and the other is used for the shampoo and water solution (the wash tank – 30L capacity). The holding tank has a porthole. The wash tank is open. When a dog is in the hydrobath a fibreglass lid is placed over the wash tank.

A garden type hose (not included with hydrobath) is connected to the holding tank to fill it. The holding tank has a ball valve arrangement to allow it to automatically refill with water. A heating element is inside the holding tank.

The controls are as follows: a switch to turn the heater on and off; a switch to turn the pump on and off; a thermostat dial; a lever to control which tank the water is being pumped from, and two levers to drain the tanks.

There are a number of ways in which the hydrobath can be used and each operator seems to adopt a way that suits them best. The basic premise involves pumping the warmed shampoo and water solution through the shower rose and recirculating this through the wash tank. The operator directs this pressurised solution through the dog's coat to remove dirt, fleas and excess sebum. Fresh heated water can then be pumped from the holding tank through the shower rose to wash the shampoo out of the coat.

The dog is removed from the hydrobath and the dirty water is drained and replaced with fresh clean water.

The usual method of operation involves using a fresh shampoo and water solution for each dog.



## SETTING UP YOUR HYDROBATH WHEN IT FIRST ARRIVES

Connect the shower rose and hose. The connection point is above the middle lever.

Tie the white cloth filter onto the flanged outlet in the wash tank (the open tank – the one without the port hole).

Check that the electrical plug is the right fit for your power socket.

## PRODUCTS AVAILABLE FOR YOUR HYDROBATH



### Fido's Shampoos & Rinses

A range of soap free shampoos, conditioners and rinses suitable for use with your hydrobath.

- Fido's Everyday Shampoo
- Fido's White and Bright Shampoo
- Fido's Black Gloss Shampoo
- Fido's Oatmeal & Baking Soda Shampoo
- Fido's Emu Oil Shampoo
- Fido's Tea Tree Oil Shampoo
- Fido's Crème Conditioner
- Fido's Herbal Shampoo
- Fido's Puppy and Kitten Shampoo
- Fido's Aloe Vera Shampoo
- Fido's Herbal Rinse
- Fido's Flea Shampoo
- Fido's Fre-Itch Rinse Concentrate
- Fido's Oatmeal Conditioner

### Fido's Hydrobath Flush Disinfectant

A disinfectant especially formulated for use with the hydrobath.



We Do Care

#### CUSTOMER SERVICE

Shirley McCormack ] - Phone 07 3808 1399  
Ricki Smith

#### NATIONAL SALES MANAGER

Martin Davis - Phone 0403 577 417

[www.fidos.com](http://www.fidos.com)

# USING THE HYDROBATH

## FILLING UP AND HEATING THE WATER IN THE HOLDING TANK

Plug the hydrobath into an electrical socket and turn the power on.

Connect a garden hose to the connection at the back of the hydrobath (1). Turn the garden tap on and the holding tank will fill up with fresh water. There is a float valve mechanism (2) (similar to that in your toilet) that automatically regulates the flow of water into this tank so you do not have to turn the garden tap off until you have finished washing dogs for the day.

There is a heating element (3) inside the holding tank. Switch this element on using the heater switch (4) at the front of the hydrobath (slide the white plastic switch downwards). A thermostat (5) next to this switch allows you to select the desired water temperature. We recommend somewhere between 25 - 30 degrees Celsius. A cut off switch inside the holding tank turns the heating element off if you run the water level too low.

It may take up to 1 hour for the water in the holding tank to heat up, so this needs to be planned for at the beginning of the working day.

## FILLING THE WASH TANK AND ADDING SHAMPOO

Have the cover of the wash tank off. This cover is the flat fibreglass floor piece.

Move the lever at the front of the hydrobath (6) to the left horizontal position.

Make sure the outside drainage levers (7) and (8) are upright to avoid emptying of the tanks. Also make sure the plug (17) is in position in the bottom of the wash tank.

Switch the pump on. The pump switch (9) is the white plastic switch next to the heater switch. Move it downwards to turn on.

The pump will draw the fresh, heated water from the holding tank into the shower hose and rose. Hold the shower hose and rose (10, 11) inside the hydrobath and direct the water into the wash tank. Turn the pump off once the wash tank is full.

Pour your shampoo directly into the wash tank (12). About 20mL of undiluted Fido's shampoo is sufficient.

Slide the lid back over the tank.

## WASHING THE DOG

Pull up the door. Put the dog inside the hydrobath. Replace the door.

Move the lever at the front of the hydrobath (6) to the right horizontal position. Switch the pump on (9).

The pump will draw the shampoo mixed with water solution from the wash tank into the shower hose and rose. This is used to wash the dog then recirculates through two filters (13, 14) back into the wash tank and out the shower rose again.

Make sure that either the plug in the bottom of the wash tank (17) is in place or that the outside drainage lever (8) is turned upright to avoid emptying of the wash tank.

Make sure that the drainage hole from the floor of the hydrobath back into the wash tank (15) is open to allow recirculation.

Also make sure that the drainage hole from the floor of the hydrobath to the outside (16) (by pass to waste drain) has a plug in it.

## RINSING THE SHAMPOO SOLUTION OFF THE DOG

Some products do not need rinsing out of the coat with fresh water. Fido's Herbal Rinse and Fido's Fre Itch Rinse Concentrate are examples. If these products have been used then the job is complete at this point.

However most shampoo products do need rinsing out of the coat with fresh water so this next step is necessary.

The wash tank is emptied by either removing the plug in the bottom of the wash tank (17) and by opening the outside drain by turning the lever (8) to the left. Gravity is generally enough to empty the wash tank so the pump doesn't have to be switched on. Replace the plug and switch the drainage lever (8) back to the upright position once empty.

Turn the lever (6) to the left horizontal position. Switch the pump on (9). Fresh,

warmed water will be drawn from the holding tank and out the shower rose. Use this water to rinse the shampoo out of the dog's coat. The most effective way of doing this is to fill the wash tank again and to recirculate this fresh, clean water through the dog's coat by switching the lever (6) to the right horizontal position.

Remove the dog once finished and start the process again for the next dog. Remember that while you are washing the first dog the holding tank will automatically refill and heat the water needed for the next dog.

## VARIATIONS TO THE ABOVE PROCESS

If the dog is extra muddy or dirty it can be rinsed initially with fresh water, then washed with shampoo and water, then rinsed again with fresh water. This initial rinse with fresh water is done by drawing water from the holding tank and having the by pass to waste drain hole (16) open. This means the initial extra rinse does not go into the wash tank at all but drains straight to the outside.


A water storage tank inside a van or trailer can be used instead of a garden tap.

## GENERAL CLEANING AND MAINTENANCE

At the end of the day fill the wash tank with water, add Fido's Hydrobath Flush Disinfectant and run the pump for 15 seconds. This cleans the pump, shower rose and drain lines.

Clean the hair and debris from the white cloth filter (14) on a regular basis (daily if washing several dogs). Replace white cloth filters when necessary.

Clean the metal filter (13) once a week. Unscrew and clean with a brush.



**MAVLAB PTY LTD**  
29-33 Rowland Street, Slacks Creek, QLD 4127  
Ph: 07 3808 1399 Fax: 07 3808 4328  
E: info@mavlab.com.au



www.fidos.com